



ARCTIC CAT Z120 POWER INTAKE INSTRUCTIONS 2009 & OLDER SUZUKI ENGINE

REVISED 6/6/2023

(IF YOU ARE ONLY INSTALLING ADJUSTABLE MAIN JET SKIP STEP #6 AND #7)

1. REMOVE COMPLETE BLACK AIR FILTER ASSEMBLY FROM ENGINE. LEAVE RUBBER BREATHER HOSE HOOKED TO BREATHER COVER.
2. REMOVE CARB FROM ENGINE BY INSTALLING BOTH CARB MOUNTING NUTS ON ONE CARB STUD AND TIGHTENING TOGETHER, AND TURNING LOOSE STUD. REPEAT THIS STEP FOR THE OTHER STUD.
3. REMOVE CARB. **KEEP TRACK OF GOV LINKAGE LOCATIONS.**
4. TURN CARB UPSIDE DOWN AND REMOVE FLOAT BOWL NUT. CAREFULLY REMOVE SMALL MAIN JET FROM CENTER OF CARB AND DRILL OUT WITH SMALL DRILL BIT SUPPLIED IN KIT. REPLACE MAIN JET AFTER DRILLING.
5. REMOVE NEEDLE FROM BRASS ADJUSTABLE MAIN JET AND INSTALL BRASS BODY IN FLOAT BOWL IN PLACE OF OEM FLOAT BOWL NUT. RE-INSTALL NEEDLE AND TURN IN UNTIL LIGHTLY SEATED, THEN BACK OUT 1 1/2 TURNS.
6. INSTALL VELOCITY STACK IN PLACE OF BLACK AIR FILTER ASSEMBLY WITH TAPER FACING OUT.
7. REMOVE OEM GOVERNOR SPRING AND INSTALL NEW SPRING IN THE EXACT SAME HOLES WITH HOOKS FACING DOWN. NOTE: TAKE UP ANY SLACK IN THROTTLE CABLE BY ADJUSTING AT CARB. **NOTE: IF THIS KIT IS BEING USED ON A 2001 TO CURRENT SNO PRO GOVERNOR ARM ADJUSTMENT IS NECESSARY.**
8. CARB TUNING PROCEDURE: START ENGINE, LET IT GET TO OPERATING TEMP, RAISE REAR OF SLED, HOLD THROTTLE IN WIDE OPEN POSITION, TURN IN MAIN JET UNTIL ENGINE STARTS TO RUN ROUGH. AT THIS POINT, TURN OUT MAIN JET UNTIL ENGINE RUNS SMOOTH, ADD 1/8 TURN OUT TO THIS SETTING. **DO NOT RUN ENGINE AT FULL THROTTLE FOR OVER 10 SECONDS WITH THE TRACK OFF GROUND.**



TECH LINE (319) 462-6932 MONDAY 8 AM TO 5PM, TUESDAY AND WEDNESDAY 8 AM TO NOON CST.

*****PLEASE NOTE*****

Manufacturer and distributor specifically disclaim all responsibility for consequential and incidental damages or any other losses arising from the use of this product. Any dispute arising out of the use of this product must be settled in Linn County, Iowa under Iowa law.
